

Free Potassium Test Strip Guide

- Test the free potassium as per instruction in the test kit
- If the levels on the strips are at maximum readable levels dilute the sample with deionized water.
- As a rule of thumb 1ml sample with 19ml of deionized water works well.

Dilution	250	450	700	1000	1500
1 + 9 ml	0.25%	0.45%	0.7%	1%	1.5%
1 + 19ml	0.5%	0.9%	1.4%	2%	3%
1 + 29ml	0.7%	1.35%	2.1%	3%	4.5%
1 + 39ml	1%	1.8%	2.8%	4%	6%
1 + 49ml	1.25%	2.25%	3.5%	5%	7.5%

1ml of Filtrate – Diluted with required level of Deionized water.

WA, EMEA

Cameron Fleming
Mobile: +61 456 429 988
Email: cfleming@mudex.com.au

Qld, Tasmania

Hamish Haliday, Area Manager
Mobile: +61 400 291 046
Email: hhaliday@mudex.com.au

SA, VIC, NT

Keith Arnett, Area Manager
Mobile: +61 438 832 822
Email: karnett@mudex.com.au

NSW, Southeast Asia

Mick Kokins, Area Manager
Mobile: +61 438 839 194
Email: mkokins@mudex.com.au